
Caller's Name Display

The Caller's Name Display Feature allows the storage of the users names in an Auxiliary computer such as a Property Management System (PMS). Problems with the link to the PMS are indicated by CND messages.

CND messages

CND0001	CND link I/O block is missing.
CND0002	CND link status block is missing.
CND0003	Garbage character received on the CND link.
CND0004	Lost partially assembled message.
CND0005	CND SDI output buffer does not get emptied properly.
CND0006	Wrong parameter passed to procedure CND_LINK_MSG_CR.
CND0007	Noisy CND Link.
CND0008	Slow response on CND link.
CND0009	CND link is down.
CND0010	CND messages are lost.
CND0011	CND link queue is not empty.
CND0012	Cannot synchronize the CND link.
CND0013	CND garbage collection pointer pointers are corrupted.
CND0014	Attempt to acquire CND name block with length zero.

CND

CND0015	Not enough memory for CND name block.
CND0016	Out of boundaries for CND name block.
CND0017	Pointer corruption while trying to remove name block.
CND0018	Name block corruption.
CND0021	Wrong TN in the Call Register.
CND0022	Special name table does not exist.
CND0023	Display's customer does not match unit's customer.
CND0024	Broken attendant queue.
CND0025	Unable to initialize CND link because of Calls Waiting in attendant queue.